

M

M96S/108S (REAR)

Kubota

FEATURES



Auxiliary Remote Control Valves

One remote valve (SCD) is standard on both the M96S and M108S. With the optional flow control valve installed, you can simultaneously operate the 3-point hitch and one remote valve, or two remote valves. Up to three remote valves can be installed in total.



Independent PTO

The PTO clutch enables the implement drive system to engage smoothly, which helps reduce operator fatigue. And because the PTO is independent, you don't have to stop the tractor to engage or disengage the PTO, saving time no matter what the task.



Floating Lift Rods

Floating lift rods are standard on the M96S and M108S. The floating position offer a smoother ride and enhanced traction while using the 3-point hitch, especially on uneven terrain.



Cat. II Hitch (Telescoping Links Standard)

The category II 3-point hitch provides fast and easy attachment of rear-mounted implements. The hitch's telescopic stabilizers and lower link ends make hook up and adjustments simple and worry-free.



Heavy-duty Drawbar

This rugged and dependable drawbar, usually found on higher-end models, has the muscle it takes to tackle your toughest tasks, such as pulling heavy trailers.

M

M96S/108S (REAR)

Kubota

FEATURES



Instrument Panel with LCD Readout

The new instrument panel makes viewing the vital functions of the tractor clear and easy. The LCD readout displays travel speed, PTO revolution and hour meter information digitally. Illuminated analog indicators include a large tachometer, temperature gauge and fuel gauge. A battery warning light has also been added to these tractors to prevent surprise battery failures, as well as indicator lights for 4WD engagement, PTO and oil pressure.



Easy Step Tilt Steering Wheel

Find the position most comfortable for you. Step on the pedal; tilt the wheel to select from among six wheel positions, and then lock it in place. Simply step on the pedal again to unlock the wheel for easy tractor mounting and dismounting.

Foldable ROPS (ROPS Model)

A foldable Rollover Protective Structure (ROPS) comes standard on the M96S and M108S. The ROPS can easily be folded down without tools so that the tractor may pass under areas with height constraints, such as doorways or low branches. (There is no operator protection provided by the ROPS in the folded position. For operator safety, the ROPS should be placed in the upright and locked position and the seat belt fastened for all other operations.)

Extra-wide Operator Platform

The M96S and M108S boast a wide platform that offers more legroom for greater operator comfort.